



INSTRUCTIONS

M SERIES KINETIC SWITCH

Product Description The M series switch is a push button style kinetic energy switch that uses micro-energy

Product Parameters

environment in the actual use

Product Series: M Series

Number of keys: 4, 6 buttons

Working Frequency: RF 433MHz

acquisition technology without battery. It can be paired with EBELONG controllers to work. If it is paired with a dimmable controller you can turn on/off /dim the lights.













Work Type: Push Button Type Power Supply: Self-powered(No battery) Communication Protocol : Ebelong 1.1 Working Temperature: -20°C~+55°C Working humidity: 5%~95%RH

Control Distance: 80m (outdoor) 25m (indoor)

Executive Standard: Q/EBL01-2018 Use Method: Pairing with EBELONG Wireless Receiving Controller Note: The effective distance data is measured by EBELONG Lab and it will vary due to the changes of the

Switch Installation

clean surface such as glass, marble, and tile.

1. Strip the Velcro film on the back of the switch

3. If necessary, remove the switch from the Velcro and use the switch as a mobile switch

(Note: Take care when removing it. If it is stuck on an unstable wall, do not remove it.)

Method 1: Use the Velcro in the package to attach the switch to a stable and

firmly to put the button back on the base.

Method 2: Open the button of the switch as shown below, and use the self-tapping screw

to lock the base of the switch to the wall by expandsion rubber or 86 type wire box, then press

expansion rubber or type 86 box

3. Press the button to replace it on the base

The ordinary pairing method is to press and hold the "pairing key" on the controller about

3 seconds and release when the light is flashing. Then press one of the group button four

times (within 1 seconds), the indicator light goes off, which means pairing is successful. After directional pairing is successful, the left button can only turn off and the right button can only turn on Long press the left button can only dim. long press the right button can

only brighten.

you can control the wireless controller by this button.

Directional Pairing with Controller

there are three groups of 6-button switch.

Pair with Controller

The M series switches need to be paired with EBELONG wireless controller. The ordinary

pairing method is to press and hold the controller "pairing key" for about 3 seconds, release

switch once. The indicator light goes off, which means that the pairing is successful. Then

In order to meet the user's habits of the switch and to ensure that the multiple controllers

Right: On and Brighten

can be turned on and off at the same time in the one-to-multiple mode, we design the direc

-tional pairing mode. Directional pairing mode is a group of two horizontal buttons, and

the "pairing key" button when the indicator light flashes, and then press a button of the M

(More detailed steps, please refer to the receiving controller instruction) If the controller is dimabele and the dimming mode is open, long press on the paired button to dim the brightness circularly and remember the brightness when you turn on the

Innovation Center, Qian Jin 2nd Road, BaoAn

commercial profit purpose.

District, Shenzhen, P.R.China

Website: www.iebelong.com

Tel: +86-755-27888758



CERTIFICATE

INSPECTED

Statement: Wireless kinetic energy switch is a product of Shenzhen EBELONG Technology Co. Ltd. The product specification and information is for reference only. Update of content will not be further notified. Except for

special agreement, information from this manual shall not constitute any form of responsibility. Without written approval from Shenzhen EBELONG

Technology Co., Ltd, no unit is allowed to copy, translate any content from

mechanical photocopying, recording etc) diffuse product information for

this manual, and shall not in any forms or by any means (electronic,

copyright Shenzhen EBELONG Technology Co., Ltd